



FRANCIS COOKE LANDFILL AND RESOURCE RECOVERY CENTRE 2018 RATES

HOURS & CONTACT: Open 8 am to 4 pm Monday to Saturday. Closed statutory holidays. All vehicles must report to the scale. To ensure “on-time” acceptance please be at the site by 3:30 pm. No loads accepted later than 3:45 pm.

Office: 403-673-2708 **Fax:** 403-673-2709 **Email:** Landfill@bvwaste.ca **Directions:** BVWaste.ca.

LITTER: Loose litter must be bagged. Please do not litter on roadways and respect our [litter policy](#). A fee is charged for loads containing loose litter or not adequately tarped. Loads with loose litter may be refused if wind is over 15 km/hr.

WEATHER: Please keep wind in mind for safe unloading. Visit BVWaste.ca for [current wind](#) conditions.

ACCEPTED MATERIALS: The Francis Cooke Landfill is a “Class III” (inert, dry waste) facility. No liquids, food, kitchen garbage, or hazardous substances are accepted. See the opposite side of this sheet for a list of common items that are not accepted. A minimum administration fee of \$100.00 plus other handling charges apply to illegal materials left on site. Please call 403-673-2708 if you are unsure whether your materials can be accepted.

FEES FOR WASTE AND RECYCLABLES

MIXED WASTE DELIVERED FOR LANDFILLING (\$/per metric tonne)

Loads containing significant amounts of easily recyclable material	226.00
Loads that do not contain significant amounts of easily recyclable material	113.00

MINIMUM FEES apply to loads under 300 kg: Residents & Non-for-Profit \$10.00, Commercial \$20.00

MATERIALS PROPERLY SEPARATED FOR RECYCLING (\$/per metric tonne)

Asphalt (clean, larger than 3ft. x 3 ft.)	100.00
Asphalt (clean & broken to 3ft. x 3 ft.)	25.00
Asphalt Shingles (clean, no tar paper, nails & staples are OK,)	55.00
Asphalt Shingles (mixed with garbage and/or tar paper, rejected for recycling)	250.00
Cover Material (clean)	12.00
Cover Material (dirty, containing large rocks, garbage or organics)	55.00
Concrete (clean & broken to 3ft. x 3 ft. or less)	55.00
Concrete (clean, larger than 3ft. x 3 ft.)	100.00
Drywall/Gypsum Board (mixed with garbage, rejected for recycling)	250.00
Drywall/Gypsum Board (clean, no plastic, wood or metal or garbage)	55.00
Metal & White Goods (including appliances, except refrigeration equipment)	20.00
Scrub & Brush, Green Wood, Stumps (no leaves, grass, dirt or other contamination)	55.00
Soft Yard & Garden (clean leaves & grass, no plastic bags, branches, food or fruit)	35.00
Wood (clean lumber, OSB, plywood, no particle board or treated wood)	79.00

OTHER CHARGES MAY APPLY IN ADDITION TO THE TIPPING FEE:

Loads Not Properly Tarpred or Properly Secured	Double the assessed tipping fee.
Sofa Surcharge per unit	Resident \$6.00, Commercial \$10.00
Mattresses and Box Springs Surcharge per unit	Resident \$10.00, Commercial \$25.00
Freon Surcharge (A/C, coolers, fridges, freezers etc.) per unit	Resident \$5.00 / Commercial \$10.00
Pressure Treated Wood	per unit (~20L Pail) \$44.00, \$220.00/tonne.
Special Handling	\$180.00 / hour.
Equipment Time	\$42.50 / hour.

PRODUCT SALES

(\$/per metric tonne, *plus \$0.25 / tonne Community Aggregate Levy)

Landscape Rock	30.00*	Rundle Rock 2” to 3”	30.00
Recycled Asphalt Product	7.50	Rundle Rock 3” to 6”	40.00
Recycled Concrete Product	2.50	Rundle Rock 6” or larger	85.00
River Rock 1” to 16”	25.00*	Sand/Gravel, Self Load	2.25*
River Rock 16” to 36”	30.00*	Sand/Gravel, Loaded	3.55*
Rundle Rock 1” and less	20.00	Topsoil (seasonable availability)	16.00
Rundle Rock 1” to 2”	25.00	Wood Chips 2”,4,” or 6” minus	8.90



Bow Valley Waste
MANAGEMENT COMMISSION

ZERO TOLERANCE FOR LOOSE LITTER INTERPRETATION

Zero Tolerance for Loose Litter means that Commission staff will not allow users of our site to unload or otherwise release any loose litter into our care that has not been contained in sturdy bags or other approved means of containment prior to arriving at the Francis Cooke Regional Class III Landfill.

BVWaste recognizes that some loose litter may escape our on-site litter management systems for a variety of reasons. In this context Zero Tolerance for Loose Litter means that BVWaste will continue to be diligent in collecting this litter within our site and beyond our boundaries.

DEFINITION

Loose litter is defined as any material that may be easily moved by wind along the ground or in the air. Loose litter includes but is not limited to:

- Plastic Foam
- Rigid Plastic
- Plastic Film
- Paper
- Cardboard
- Fibreglass/Styrofoam or Other Lightweight Insulation Materials

Loose litter does not include leaves and grass.

ENFORCEMENT

Users of our site who do not comply with the need to contain loose litter will be refused the opportunity to unload on our site or may be subject to other actions according to the circumstances. For the purpose of enforcing our policy of Zero Tolerance for Loose Litter “wind” is considered to **be average wind speed greater than 15 kilometres per hour measured by the Francis Cooke weather station.**

CURRENT WIND SPEED

The current wind speed at the landfill is available from any internet connection by selecting the “**CURRENT WIND & WEATHER**” links on the Home or Landfill pages of our web site (BVWaste.ca), loading the “Davis Instruments” app on your iPhone, or calling the scale office at 403-673-2708.



FRANCIS COOKE WIND AND WEATHER INFORMATION AVAILABLE ON THE WEB

Follow these instructions to find up to the minute Francis Cooke weather station information. You can place it as a “favourite” or “bookmark” on your computer, smart phone or other device and download the app directly to your iPhone.

IPHONE APP SETUP:

- 1/ Connect to the “App Store” through your iPhone.
- 2/ Choose the search option.
- 3/ Enter “Davis Instruments”.
- 4/ Download the app and press “open”.
- 5/ Select “+” in the lower left of the screen and the list of stations is displayed.
- 6/ Select “+” in the upper left of the screen and enter “bvwaste”.
- 7/ Choose Francis Cooke Regional Landfill from the list of weather stations.
- 8/ Press “Done” and select Francis Cooke Regional Landfill on the App home page.
- 9/ Select the “i” in the lower right to set how you want the information displayed.
- 10/ You will need to set the wind speed units to display in “km/h” to be consistent with how we measure wind and enforce our loose litter policy (see back side of this page).
- 11/ Select “Done”. Be sure the Francis Cooke weather station is selected.
- 12/ Select the first (far left) dot at the bottom of your screen to show the current weather.

Add or remove stations in the App list by selecting “+” then selecting the red delete (-) icon beside the station’s name or search for another station you are interested in by selecting the “+” icons.

BOOKMARK OR FAVOURITE ON COMPUTER, PHONE OR TABLET:

- 1/ Go to the BVWaste web site BVWaste.ca.
- 2/ Scroll down the Home OR Landfill Page to: **“LANDFILL & RECYCLING ESSENTIALS”**.
- 3/ Scroll down to: **“CURRENT [WIND & WEATHER](#)”**
- 4/ Click on the words “Wind and Weather” which should be blue as shown above.
- 5/ This link will take you to our weather station information.
- 6/ Once the station information is displayed save it as a “favourite” or a “bookmark” in your browser for quick reference from anywhere you are connected to the web. Use the “Map” link to find other stations you are interested in.

